

# MONTEREY PENINSULA AQUIFER STORAGE AND RECOVERY PROJECT SAMPLING AND ANALYSIS PLAN

### Prepared for:



December 2012

December 2012 Project No. 06-0025 Monterey Peninsula ASR Project – Sampling and Analysis Plan



## MONTEREY PENINSULA AQUIFER STORAGE AND RECOVERY PROJECT

#### **GROUNDWATER SAMPLING AND ANALYSIS PLAN**

#### INTRODUCTION

This Groundwater Sampling and Analysis Plan (SAP) has been developed for the Monterey Peninsula Aquifer Storage and Recovery (ASR) Project. The project is cooperatively implemented by the Monterey Peninsula Water Management District (MPWMD or District) and California American Water (CAW), and generally involves the diversion of excess winter/spring flows from the Carmel River system for recharge, storage and subsequent recovery in the Seaside Groundwater Basin (SGB). Treated (potable) drinking water from the CAW distribution system is injected into the Santa Margarita Sandstone aquifer in the SGB via three existing ASR wells located at two ASR facilities in the SGB. The injected water is stored within the aquifer and subsequently recovered into the CAW distribution system during dry periods. The overall objective of the project is to facilitate the conjunctive use of water supplies in the Carmel River system and SGB that will benefit the resources of both systems.

ASR operations generally consist of three components or phases: (1) injection of drinking-quality water into the aquifer through the ASR wells; (2) storage of the injected water within the aquifer; and, (3) recovery of the stored water by pumping at one or more of the ASR wells. Periodic samples of the injected, stored, and recovered waters are to be collected from the ASR wells and associated monitoring wells and analyzed for a variety of water-quality constituents pursuant to requirements of the Central Coast Regional Water Quality Control Board (RWQCB) for the project. The purpose of this SAP is to identify the locations, sample collection frequency, and parameters to be monitored as part of the project's ongoing water-quality data collection program. The project location and associated wells in the SGB are shown on **Figure 1** – Project Location Map.

#### **GROUNDWATER MONITORING**

#### **Groundwater Monitoring Wells**

ASR Project On-Site Wells. There are two ASR facilities located in the SGB; the Santa Margarita and Seaside Middle School ASR Facilities. Groundwater monitoring wells for collection of on-site water-quality samples include three ASR wells and two associated monitoring wells that have been constructed at the two ASR facilities. Two of the ASR wells are located at the Santa Margarita (SM) ASR Facility and are designated as SM ASR-1 and SM ASR-2. This facility is also referred to as the Phase 1 ASR Project. The third existing ASR well is located at the Seaside Middle School (SMS) ASR Facility and is designated as SMS ASR-3.

December 2012 Project No. 06-0025 Monterey Peninsula ASR Project – Sampling and Analysis Plan



This facility is also referred to as the Phase 2 ASR Project<sup>1</sup>. All three existing ASR wells are completed solely within the Santa Margarita Sandstone (Tsm) aquifer.

In addition to the ASR wells, there are two on-site monitoring wells (one located at each ASR facility) that are also completed solely within the Tsm aquifer. SM MW-1 is located at the SM ASR Facility and is located in between SM ASR-1 and SM ASR-2, at distances of approximately 90 and 190 feet, respectively. SMS Deep MW is located at the SMS ASR Facility at a distance of approximately 20 feet from SMS ASR-3. An additional monitoring well is also located at the SMS ASR Facility that is completed within the overlying Paso Robles aquifer, designated as SMS Shallow MW. This well is instrumented with a submersible water-level transducer/data logger unit to observe the water-level response of this aquifer to ASR operations (it is not designed or equipped for collection of water-quality samples). The locations of the ASR wells and on-site monitoring wells are shown on **Figure 2** – Site Location Map. A summary of the on-site wells is presented in **Table 1** below:

Table 1. On-Site Wells Summary

Well ID	Dista	Aquifer Completed		
	SM ASR-1	SM ASR-2	SMS ASR-3	Completed
SM ASR-1		280	1,380	Tsm
SM ASR-2	280		1,235	Tsm
SM MW-1	90	190	1,325	Tsm
SMS ASR-3	1,380	1,235		Tsm
SMS Deep MW	1,380	1,240	20	Tsm
SMS Shallow MW	1,415	1,265	25	QTp

Table 1 Notes:

Tsm - Santa Margarita Sandstone aquifer

QTp - Paso Robles aquifer

Off-Site SGB Wells In addition to the on-site wells at the two ASR facility sites, submersible water-level transducer/data logger units have been installed at seven off-site District monitoring well sites in the SGB to observe the water-level response of the aquifer system to ASR operations. The locations of the off-site monitoring wells are shown on **Figure 1**. The distances from each of the project sites and aquifers monitored by the off-site wells are summarized in **Table 2** below:

<sup>&</sup>lt;sup>1</sup> The Phase 2 ASR Project will consist of two ASR wells and associated facilities at the SMS ASR Facility. SMS ASR-4 is currently planned to be installed during summer/fall of 2012 and will be added to the SAP when completed and equipped for operation.

Monterey Peninsula ASR Project – Sampling and Analysis Plan

**Table 2. Off-site Monitoring Wells Summary** 

Well ID	Distance fro	Aquifer Monitored		
	SM	SMS	ino into i cu	
Paralta Test	680	740	QTp & Tsm	
Ord Grove Test	1,540	2,535	QTp & Tsm	
Ord Terrace (Deep)	2,275	2,910	Tsm	
FO-7 (Deep)	4,265	3,700	Tsm	
FO-7 (Shallow)	4,200	3,700	QTp	
PCA East (Deep)	6,390	6,200	Tsm	
PCA East (Shallow)	0,390	0,200	QTp	
FO-9 (Deep)	7,290	6,125	Tsm	
FO-8 (Deep)	7,585	6,450	Tsm	

Table 2 Notes:

Monitoring well distances are measured to centroid of each ASR site.

Tsm - Santa Margarita Sandstone aquifer

QTp - Paso Robles aquifer

In addition to water-level monitoring at the above off-site monitoring wells, CAW's Paralta well and PCA East Deep have been designated as off-site monitoring wells for periodic water-quality sampling as part of this SAP (refer to **Table 4**).

#### **Groundwater Monitoring Equipment**

The equipment required to perform the groundwater monitoring as prescribed in the SAP includes:

- Sampling Pumps
- Pressure Transducers/Data Loggers
- Electric Water Level Sounder
- Field Water Quality Monitoring Devices
- Flow-Thru Cell Device(s)
- Sample Containers
- Coolers and Ice

Each of the on-site wells is equipped with a dedicated pump. The ASR wells are equipped with water-lubricated, vertical line-shaft turbine pumps. SM MW-1, SMS Deep MW, and PCA East Deep are equipped with submersible sampling pumps. The flow rates for each monitored wells are measured using in-line flow meters. Sampling ports on the well-head piping at each well allow for the collection of grab samples during injection and pumping operations.

December 2012
Project No. 06-0025
Monterey Peninsula ASR Project – Sampling and Analysis Plan



Field water-quality monitoring is to be performed using various instruments that allow for the field analysis of a variety of constituents, including but not limited to: chlorine residual, conductivity, dissolved oxygen, pH, temperature, redox/ORP, and Silt Density Index (SDI). The field water-quality monitoring devices are to be routinely calibrated as prescribed in the operating procedures manual for each device.

All of the ASR and monitoring wells are instrumented with dedicated pressure/level transducers and dataloggers. Reference-point elevations have been established by surveying on each of the monitored wells. Static water-levels in each of the wells are to be measured with an electric sounder on a quarterly basis (minimum) and the transducers calibrated accordingly. The transducers are to be programmed with the reference static water-level and the data-collection interval, which will measure and record the water level in each of the wells a minimum of four times per day.

#### **Purging and Sampling**

During injection periods, samples of the injectate are to be collected directly at one of the ASR wellheads while active injection is occurring. During storage periods, each of the ASR wells that has been utilized for injection during the season will be periodically purged and sampled. During recovery periods, one or more of the ASR well pumps will be operating and purging is continuous and sustained. Groundwater samples are also to be collected routinely during all three ASR periods (i.e., injection, storage and recovery) from both the on-site monitoring wells (SM MW-1 and SMS Deep MW) and periodically from the far-field off-site monitoring wells (Paralta and PCA-E Deep).

The existing pumps will be used to purge a volume equivalent to a minimum of three (3) casing volumes from the well prior to sampling. Purge water from the ASR wells during backflushing and sampling is to be discharged to the backflush pit at the SM ASR Facility and percolated back into the SGB. Water produced by the ASR well(s) during recovery period operations is to be discharged to the CAW potable water supply system (in accordance with Department of Public Health approvals). Purge water from the monitoring wells will be directed to either the SM backflush pit or to the ground away from the wellheads and percolated back into the SGB.

During purging and prior to sampling, field water-quality parameters of temperature, pH and specific conductance are to be monitored. Stabilization of these water-quality parameters will indicate when collection of a representative sample is obtainable.

#### Chain-of-Custody, Sample Handling, and Transport

All samples collected will be labeled in a clear and precise way for proper identification in the field and for tracking in the laboratory. All sample shipments for analyses will be accompanied by a chain-of-custody record. Forms will be completed and sent with the samples for each shipment. The chain-of-custody form will identify the contents of each shipment and

December 2012 Project No. 06-0025 Monterey Peninsula ASR Project – Sampling and Analysis Plan



maintain the custodial integrity of the samples. Samples will be placed in a cooler for delivery to the laboratory.

#### **Documentation Procedures**

Field data will be recorded by field personnel on the attached Field Sampling Log Form and routinely submitted to the Project Manager for review and QA/QC. Field data will include the completed field sampling-log form and chain-of-custody records. At a minimum, documentation of each monitoring and sampling event will include the following information:

- Sample location and description
- Sampler's name(s)
- Date and time of sample collection
- Type of sampling equipment used
- Field instrument calibration procedures and results
- Field instrument readings
- Field observations and details related to analysis or integrity of samples (e.g., weather conditions, noticeable odors, colors, etc.)
- Sample preservation
- Shipping arrangements
- Name(s) of recipient laboratory
- Any deviations from SAP procedures

Project information will be filed by Water Year. The project file will contain project field data, correspondence, survey reports, laboratory reports, charts, tables, permits, and other project-related information. This information will be utilized in the preparation of the annual Summary of Operations Reports for the project.

#### LABORATORY PROGRAM

A complete list of constituents and constituent "groups" to be monitored as part of the ASR Project for injected, stored, and recovered waters is presented in **Table 3** below. **Table 4** summarizes the planned sample constituent group frequencies for each source for the injection, storage, and recovery periods.

December 2012 Project No. 06-0025 Monterey Peninsula ASR Project – Sampling and Analysis Plan



**Table 3. Analytic Testing Program Constituent Summary** 

Constituent	PQL	General Parameters	Disinfection Byproducts	Supple- mental	Field <sup>1</sup>
Group ID		G-1	DBP	S-1	F-1
Major Cations					
Calcium (Ca)	1 mg/L	✓			
Magnesium (Mg)	1 mg/L	✓			
Sodium (Na)	1 mg/L	✓			
Potassium (K)	0.5 mg/L	✓			
Major Anions					
Total Alkalinity (as CaCO <sub>3</sub> )	10 mg/L	<b>✓</b>			
Sulfate (SO <sub>4</sub> )	1 mg/L	<b>✓</b>			
Chloride	1 mg/L	✓	✓		
Nitrate as (NO3)	1 mg/L	<b>✓</b>			
Nitrite as (Nitrogen)	0.1 mg/L	✓			
General Physical					
рН	0.1 units	✓			✓
Temperature	0.5 °C				✓
Specific Conductance (EC)	10 uS	✓			✓
ORP (redox potential / Eh) <sup>2</sup>	10 mV				✓
Total Dissolved Solids (TDS)	10 mg/L	✓			
Metals					
Arsenic (As)	1 ug/L			✓	
Barium (Ba)	0.5 mg/L			✓	
Iron (Fe) (Total and Dissolved)	50 ug/L	✓			
Lithium (Li)	5 ug/L			✓	
Manganese (Mn) (Total and Dissolved)	10 ug/L	✓			
Molybdenum (Mo)	5 ug/L			✓	
Nickel (Ni)	10 ug/L			✓	
Selenium (Se)	5 ug/L			✓	
Strontium (Sr)	5 ug/L			✓	
Uranium (U)	1 pCi/L			✓	
Vanadium (V)	5 ug/L			✓	
Zinc (Zn)	0.5 ug/L			✓	
Miscellaneous	ı	1		ı	ı
Ammonia (as N)	0.05 mg/L	✓			
Boron (B)	0.05 mg/L	✓			
Chlorine residual (free)	0.1 mg/L				✓

December 2012 Project No. 06-0025 Monterey Peninsula ASR Project - Sampling and Analysis Plan



Constituent	PQL	General Parameters	Disinfection Byproducts	Supple- mental	Field <sup>1</sup>
Group ID		G-1	DBP	S-1	F-1
Chloramines	50 ug/L		✓		
Dissolved Methane	0.5 ug/L			✓	
Dissolved Oxygen (DO) <sup>2</sup>	0.025 mg/L				✓
Gross Alpha	1 pCi/L			✓	
Hydrogen Sulfide (H₂S)	0.05 mg/L				✓
Total Nitrogen (N)	0.2 mg/L	✓			
Total Phosphorous	0.05 mg/L	✓			
Orthophosphate as P	0.05 mg/L	✓			
Radium 226	1 pCi/L			✓	
Silt Density Index (SDI)	0.1 units				✓
Total Kjehldahl N (TKN)	0.2 mg/L	✓			
Organic Analyses					
Total trihalomethanes	1 ug/L		✓		
Bromodichloromethane	1 ug/L		✓		
Bromoform	1 ug/L		✓		
Chloroform	1 ug/L		<b>√</b>		
Dibromochloromethane	1 ug/L		<b>√</b>		
Haloacetic Acids (HAA)	1 ug/L		<b>√</b>		
Monobromoacetic Acid	1 ug/L		<b>√</b>		
Monochloroacetic Acid	1 ug/L		<b>√</b>		
Dibromoacetic Acid	1 ug/L		✓		
Dichloroacetic Acid	1 ug/L		<b>√</b>		
Trichloroacetic Acid	1 ug/L		<b>√</b>		
Total organic carbon (TOC)	0.1 mg/L	✓			
Dissolved organic carbon (DOC)	0.1 mg/L	✓			

Table 3 Notes:

<sup>1 –</sup> Field Parameters (Group F-1) must be taken concurrently with collection of all laboratory samples. 2 – ORP and DO must be analyzed utilizing a flow-thru cell device.

December 2012 Project No. 06-0025 Monterey Peninsula ASR Project – Sampling and Analysis Plan



#### **Table 4. Analytic Testing Program Schedule**

IN IECTION PERIOD (setting in legation)								
INJECTION PERIOD (active injection)								
Analyte Group	Injectate			SM MW-1	SMS Deep MW	PCA East (deep)		
F-1		Bi-Weekly		Bi-Weekly	Bi-Weekly	Semiannually		
DBP		Monthly		Quarterly	Quarterly	Semiar	nually	
G-1		Quarterly		Quarterly	Quarterly	Semiannually		
S-1		Quarterly		Quarterly	Quarterly	Semiannually		
STORAGE PERIOD (one month duration or longer)								
Analyte Group	SM ASR-1	SM ASR-2	SMS ASR-3	SM MW-1	SMS Deep MW	PCA East (deep)		
F-1	Monthly	Monthly	Monthly	Quarterly	Quarterly	Semiannually		
DBP	Quarterly	Quarterly	Quarterly	Quarterly	Quarterly	Semiannually		
G-1	Quarterly	Quarterly	Quarterly	Semiannually	Semiannually	Semiannually		
S-1	Quarterly	Quarterly	Quarterly	Semiannually	Semiannually	Semiannually		
	RECOVERY PERIOD							
Analyte Group	SM ASR-1 <sup>1</sup>	SM ASR-2	SMS ASR-3	SM MW-1	SMS Deep MW	Paralta	PCA East (deep)	
F-1	Bi-Weekly	Monthly	Monthly	Quarterly	Quarterly	Semiannually <sup>2</sup>	Semiannually	
DBP	Quarterly	Quarterly	Quarterly	Semiannually	Semiannually	Semiannually <sup>2</sup>	Semiannually	
G-1	Quarterly	Quarterly	Quarterly	Semiannually	Semiannually	Semiannually <sup>2</sup>	Semiannually	
S-1	Quarterly	Quarterly	Quarterly	Semiannually	Semiannually	Semiannually <sup>2</sup>	Semiannually	

Table 4 Notes:

<sup>1-</sup>SM ASR-1 is currently the only ASR well authorized by DPH to recover into the CAW distribution system.

<sup>2 –</sup> Near the beginning and end of the SGB production/recovery season (e.g., in June and November).





FIGURE 1. PROJECT LOCATION MAP Monterey Peninsula ASR Project Sampling and Analysis Plan





FIGURE 2. SITE LOCATION MAP Monterey Peninsula ASR Project Sampling and Analysis Plan





#### **Monterey Peninsula ASR Project** Field Sampling Log Form Water Year:

Well ID	: 		_				
Observer	:		_				
Date	:		_				
Observation Period	: Start:	Stop:		_			
Weather	:						
Purging & Wa	ater-Level Data			Notes:			
	on, storage, recovery)						
Well Status (injecting							
Purge Rate (gpm)							
Totalizer Reading St	art (gals)						
Totalizer Reading at	Sampling (gals)						
Purge Volume (gals)	)						
Totalizer Reading Er	nd (gals)						
Static Water Level (1	ft btoc) <sup>1</sup>						
Datalogger Water Le	evel (ft btoc)						
Field Water-C	<b>Quality Paramete</b>	er Data					
	Time:						
	Elapsed Time:						
Temperature (°C)							
Conductivity (umhos	s/cm)						
pН	·						
ORP (mV) <sup>2</sup>							
Free Chlorine Resid	ual (mg/L)						
Dissolved Oxygen (r	ng/L) <sup>2</sup>						
Silt Density Index							
Gas Volume (mL)							
H2S (mg/L)							
Visual Observations							
Sampling and	l Laboratory Da	ıta					
Collection Time	Laboratory	Laboratory	Analyses Rec	guested (anal	yte group or o	ther constit	uents)
					<i>y.o.g.op.o.</i>		
Additional Inf	ormation and C	)bservat	ions				
			· - · · · ·				
l							

- 1 Pump must be off a minimum of 10 minutes prior to measuring.2 ORP and Dissolved Oxygen must be analyzed utilizing a flow-thru cell device